


lifelong

KITCHEN

MAKING IT POSSIBLE

POWER PRO
JUICER
MIXER
GRINDER
450W



Ergonomic
& Elegant



Powerful
Motor



Speed
Selection



Large
Capacity Jar

1 YEAR
WARRANTY

Dear Customer

Congratulations on your Lifelong Purchase. Our name stands for high-quality and thoroughly tested products. This amazingly versatile home appliance will help reduce your kitchen drudgery. This Lifelong power pro juicer mixer grinder 450W is a great time saver and a helpful gadget.

Please read these instructions carefully before use.



MAIN PARTS

1. Pusher.
2. Top Cover.
3. Handle.
4. Rotatory Switch.
5. Main Body.
6. Liquidizer Jar.
7. Multipurpose jar/Digi Jar

HOW TO USE YOUR BLENDER/GRINDER

1. Pull out the clamps which are on both sides of main body and remove the middle body.
2. Place jar firmly on the main body coupler and twist jar to fit intact.
3. Put all ingredients into the steel container and place jar firmly on the Jar.
4. Rotate speed selector key as per requirement. Rotate key marked OFF to stop blender/grinder.

THE RIGHT FUNCTION FOR RIGHT UTILITY

It is vitally important to determine the correct speed to stir, blend, chop, liquify or grind. Press various speed keys to find the best result.

Wet Grinding: No anxiety and no labour, now you can get paste/chutneys or whole spices, coconut etc... in no time.

Dry Grinding: Grinding Coffee beans, spices, coarsely crumb bread, granulated sugar etc. will be easy and simple.

CLEANING AND MAINTAINENCE

1. Wash each part(except main body) in cold or lukewarm water. The juicer mesh also functions as filter so wash with extra care.
2. After washing, wipe wet surface to dry perfectly.
3. Please do not spill any water on the motor.

OVERLOAD PROTECTION

1. In order to avoid any possibler motor burning due to overloading, this Juicer Mixer Grinder is fitted with overload protector.
2. If the machine sometimes stops while in operation this is a warning that your juicer is overload. Switch OFF the Juicer and wait fot 2-3 minutes.

3. Allow the motor to cool down and also remove the cause of overload. The red button of the thermal relay switch located on the base plate of the juicer has to be pressed by hand for re-operation.

SAFETY INSTRUCTIONS

1. After using, turn OFF electric switch and disconnect plug.
2. Do not remove or replace steel jars when the motor is ON.
3. Do not overload the motor by hard and heavy loads.
4. Do not heat parts or wash in hot water.
5. Do not put ice cubes into jar without adding one cup or more of any desired liquid.
6. Do not grind raw meat in jar.
7. Do not store food in jar.
8. Always cool all hot vegetables, fruits and sauces before putting into jar.
9. Do not operate the unit without load.
10. Whenever stirring dry ingredients, do not run motor for more than a few seconds. Any operation for longer periods will damage the precision bearing in cutter assembly.
10. Do not worry if you experience some burning smell when you run your mixer grinder for the 1st time. This is due to the motor varnish getting heated for the 1st time. The problem should not recur in subsequent uses. If it does, please contact our customer care.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Terms and Conditions:

1. This warranty is void if:

- a. The completely filled warranty card is not presented at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
- e. Product label specifying the model number, serial number and production code has been removed and altered.
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.

2. Repairs or replacements will be carried out by authorized service provider.

3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised service.

4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.

6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.

7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.

8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by :

Lifelong Online Retail Private Limited
Made in India

For queries and complaints:
please contact: customercare@lifelongindia.com
www.lifelongindiaonline.com