


وملعنا

HAIR DRYER
LLPCW02



Easy to Carry



Powerful Drying



2 Speed Function



Hair Dryer

Model: LLPCW02

TECHNICAL DATA

Colour :	Black
Voltage :	220-240V 50Hz
Wattage:	1000W

IMPORTANT SAFEGUARDS

When using electrical appliance, basic safety precautions should always be observed, including the following:

- Check if the voltage indicated on the appliance corresponds to the local voltage before you connect the appliance

Terms and Conditions:

1. This warranty is void if:
 - a. The completely filled warranty card is not presented at the time of servicing the product.
 - b. The product is not operated according to the instructions given under the user manual.
2. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
3. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
4. Product label specifying the model number, serial number and production code has been removed and altered.
5. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
6. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
7. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
8. Repairs or replacements will be carried out by authorized service provider.
9. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised service provider.
10. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.
11. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
12. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
13. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
14. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by :
Lifelong Online Retail Private Limited
Made in China
For queries and complaints:
please contact: customercare@lifelongindia.com
www.lifelongindiaonline.com

6. Neither should the appliance be used with wet hands nor immersed in water, held in running water, or allowed to become wet
7. Do not use the hair dryer for purposes other than drying and styling human hair
8. Do not pull the cord with unnecessary force. Do not wrap the cord around the unit. Check cord regularly for any sign of damage. Damaged cords can be dangerous
9. Always switch the appliance off before putting it down, even if it is only for a moment
10. Always unplug the appliance after use

INSTRUCTION FOR USE

- Put the plug in the wall socket
- Switch the appliance on by selection of the desired setting
- The airflow and temperature can be adjusted
- Dry your hair by making brushing movements while holding the dryer at a small distance from your hair

CARE AND CLEANING

- Switch off the hair dryer, unplug from the power supply
- Wipe over the housing using a soft damp cloth
- Remove and wash the concentrator and removable rear grill in warm soapy water
- Do not use hard abrasives or cleaners
- Ensure all parts are dried thoroughly with a soft dry towel

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

USAGE WARNING

Do not use this product near or over water in bathtubs, basins or other vessels

1. When the hair dryer is used in a bathroom, unplug the appliance after use since the proximity of water presents a hazard, even when the hair dryer is switched off
2. For additional protection, we advise you to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA in the electrical circuit supplying the bathroom.
3. Never block the air grilles
4. If the appliance overheats, it will switch off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grilles to make sure they are not blocked by fluff, hair, etc
5. Do not direct the airflow towards the eyes or other sensitive areas