


TEMPERATURE CONTROL HAIR STRAIGHTENER











MAKING IT POSSIBLE

Lifelong Temperature Control Hair Straightener Model No.: LLPCW20



Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from them date of purchase.

Name of the product:

Model:

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification. Customer Care: customercare@lifelongindia.com

Customer Details

Name:	
Address:	
Home Number:	
E-mail Address:	

Product Details

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

- 1. It get's heated up within 30 seconds and thus you do not need to wait for long. It gives you poker straight hair in a fraction of the time.
- 2. The ceramic technology prevents hair from getting frizzy and makes them smooth and soft.
- 3. The handle is long and it helps in easy handling which makes things simpler.
- 4. This straightener has 2 inch plates size so that you can straight large sections which saves your time.

SPECIFICATIONS

- Rated voltage: 220-240V~, 50/60Hz, 47W
- Max Temperature 220°C
- Dimensions: 251 x 41.1 x 32.35 mm
- Ceramic coated plates
- Weight of the unit: 312G
- Length of Cord: 1.8M
- Within 30 seconds, the temperature warm up to 200°C
- Auto off after one hour

HOW TO USE

1. Connect the plug to a power supply socket.

2. Press the switch on, press the button. You can change the temperature from 180°C to $220^{\circ}\text{C}.$

It will be heat up to the desired temperature within seconds.

3. Comb your hair and take a hair strand to straighten.

4. Place it between the straightening plates and press the handles together.

5. Slide the straightener down the length of the hair in a single motion (max.

5 seconds) from root to end, without stopping to prevent overheating.

- 6. Switch off the appliance and unplug it.
- 7. Place it on a heat-resistant surface until it cools down.
- 8. Clean the appliance and straightening plates with damp cloth.
- 9. Lock the straightening plates.
- 10. Keep it in a safe and dry place, free of dust. You can also hang it with the hanging loop.

Terms and Conditions:

1. This warranty is void if:

- a. The completely filled warranty card is not presented at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- C. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
- Product label specifying the model number, serial number and production code has been removed and altered.
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
- 2. Repairs or replacements will be carried out by authorized service provider.
- During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
- All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as will as any other expenses and incidentals will be borne by the consumer.

- 5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warrantied, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the lass.
- 6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
- 7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss,) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
- No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by : Lifelong Online Retail Private Limited

Made in China For queries and complaints: please contact: customercare@lifelongindia.com www.lifelongindiaonline.com

Dear Customer

Thank you for purchase of the Lifelong Hair Straightener. Please read the instructions below before operating:

IMPORTANT

- 1. If the main cord is damaged, it must be replaced by manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- 2. When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
- 3. Don't touch the high temperature area in order to avoid injury when the straightener in use.
- 4. Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.
- 5. Do not use the appliance for any other purpose than described in this manual.
- 6. When the appliance is connected to the power, never leave it unattended.
- 7. Do not wind the mains cord round the appliance.
- 8. Wait until the appliance has cooled down before you store it.
- Pay full attention when using the appliance since it could be extremely hot. Only hold the handle as other parts are hot and avoid contact with the skin.
- 10. Keep the appliance away from flammable objects and material when it is switched on.