




Smart Touch Switch















#### **SPECIFICATIONS**

Input Voltage: 100-240VAC 50-60Hz

Maximum Output Power per Channel: 800W Wireless Standard: Wifi 802.11 b/g/n 2.4GHz Control Method: APP/Button Touch/ Voice Control

**Housing Material:** PC flame retardant **Panel Material:** Tempered glass

Standby power consumption: ≤0.03W


Working humidity: <80%

Operating temperature: -40 C-85°C

Panel size: 86\*86\*33 mm Carton size: 115\*110\*50 mm

#### **INSTALLATION NOTES**

1. Please install according to the wiring diagram given below.



#### Note:

Please ask for help from a professional electrician and switch off AC mains before installing.


### **INSTALLING THE DEVICE**

How should I install the product?

Get local electrician to install the product.

You must call your local Electrician to install the product. And show him below diagram to make him understand.

Please ask your electrician to bring 3x3 inches electrical box to fit the smart switch.



Fit the back of the smart switch in 3x3 inches electrical box

Close the back and front of the smart switch together.

## **INSTALLING THE APP**

1. Please scan the QR code below to download the "Lifelong Smart" Home App. Available both on iOS and Android Phones.



- 2. Register using an email address.
- 3. On the registration page, click on "Get Verification Code" and enter the code once received.
- 4. Set your password and click "OK" to register.



<

# Register



#### **ADDING THE DEVICE**

- 1. Make sure your mobile phone is connected to Wifi.
- 2. Power up the smart touch switch.
- 3. In the Lifelong Smart App home page, tap the icon "+" on the top right corner or click the "Add Device" button.
- 4. Select "Add Manually" from the top carousel.
- 5. Select "Touch Switch". This will take you to the device detection page.
- 6. Once on the detection page, Reset the device by pressing any touch button for more than 3 seconds. An indicator should then start blinking.
- 7. In the App, Press the "Confirm indicator rapidly blink" button.
- 8. In the next screen, enter your Wifi name and password.
- 9. The device will get connected automatically and you will be taken to the Device

screen in the App.

- 10. By default, the name of the device will be "Three-Gang Switch". You can edit it to any suitable name.
- 11. Your device is now connected and ready to use.















#### **BINDING AMAZON ALEXA**


- 1. You can connect your device to Amazon Alexa easily by Amazon Alexa app.
- 2. Navigate to the "Skills & Games" menu in Alexa app.
- 3. Press search and enter "Lifelong Smart". In the results click "Lifelong Smart Home".

This will take you to the Lifelong Smart Skills page.

- 4. Click "Enable to use". You will then need to enter your Lifelong Smart account login
- details and press "Link Now".
- 5. In a few seconds your account will be linked to Alexa skills and a success notification is presented. Press "Close".







#### **VOICE CONTROL WITH ALEXA**

To control your device using Alexa, it is recommended to connect it to an Amazon Echo device. Echo needs to discover your device first. To discover, you can say "Alexa, discover device". If the device has already been discovered during Alexa setup as described above, this step can be omitted.

To control your device with voice commands, you can use following commands (assuming you have named one switch as Bedroom Light) -

- 1. Alexa, turn on bedroom light.
- 2. Alexa, turn off bedroom light.
- 3. Alexa, switch on bedroom light after 2 hours.
- 4. Alexa, switch off bedroom light after 6 hours.

#### **Consumer Warranty Card**

Dear Customer

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service All Lifelong consumer products are covered against manufacturing defects from them date of purchase.  Name of the product:  Model:  Warranty coverage: 1 year
Please note: Purchase receipt is necessary for warranty verification.  Customer Care: customercare@lifelongindia.com
Customer Details Name: Address: Home Number: Office Number: E-mail Address:
Product Details  Model No.: Serial No.: Purchase Date: Invoice Number: Online Site:
Please log onto to www.lifelongindiaonline.com and complete the online warranty form with you

#### Terms and Conditions:

- 1. This warranty is void if:
  - a. The completely filled warranty card is not presented at the time of servicing the product.
  - The product is not operated according to the instructions given under the user manual.
  - C. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
    d. Product has been damaged due to installation.
- repairs, alterations or modifications by unauthorized service organizations or persons.

  e. Product label specifying the model number, serial
- e. Product label specifying the model number, seria number and production code has been removed and altered.
- Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
- Repairs or replacements will be carried out by authorized service provider.
- During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
- All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as will as any other expenses and incidentals will be borne by the consumer.

- 5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warrantied, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the lass.
- 6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tot) shall not exceed the original purchase price paid for the product.
- 7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
- No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by : Lifelong Online Retail Private Limited

For queries and complaints: please contact: customercare@lifelongindia.com www.lifelongindiaonline.com