


lifelong

HOME

MAKING IT POSSIBLE

DIRECT COOL SINGLE DOOR REFRIGERATOR



Sleek &
Compact Design



Quiet Operation



Environment-friendly
Refrigerant



Easy Temperature
Control Knob

1 YEAR
PRODUCT WARRANTY

5 YEAR
COMPRESSOR WARRANTY

Index:

Features

Important Safety Instructions

Know Your Product

Installation Method

Operating Instructions

Maintenance and Care

Technical Specifications

Diagram of electrical principle

Packing list

Warranty Terms and Conditions

E-waste management



■ This symbol on the products and or accompanying documents means that used electrical and electronics products should not be mixed with general household waste. For proper treatment, recoveries, recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis.

FEATURES:

- ***Mechanical temperature control thermostat***
- ***50 Litres capacity***
- ***Adjustable legs***
- ***Separate chiller compartment***
- ***Manual defrost***
- ***Mini Size - place saving & easy to move***
- ***VCM finish outer body***

Important Safety Instructions:

WARNING	To reduce the risk of fire, electric shocks, or personal injury while using your refrigerator, follow these basic precautions:
<ul style="list-style-type: none">◆ Read all the instructions carefully before using the refrigerator.◆ DANGER or WARNING: Risk of child entrapment.◆ To avoid the possibility of child entrapment; please take the following precautions before disposing off the refrigerator.<ul style="list-style-type: none">- Remove all doors from the unit.- Keep the shelves out of reach of small children◆ This appliance can be used by children, 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.◆ Children should not be allowed to play with the appliance.	

◆ Cleaning and maintenance of the fridge should not be done by children without proper supervision.

◆ Do not store explosive substances such as aerosol cans with flammable propellant inside the refrigerator.

◆ This appliance is intended to be used for household use and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;

WARNING

Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, get it replaced by Lifelong authorized service personnel.

This refrigerator should be properly grounded for your safety. The power cord of this refrigerator is equipped with a three-prong plug which matches with standard three prong wall outlets to minimize the possibility of electrical shock.

Do not, under any circumstances, remove the grounding plug from the power cord.

This refrigerator requires a standard 220-240V- /50 Hz electrical outlets with three-prong ground.


This refrigerator is not designed to be used with an inverter.

The cord should be secured behind the refrigerator and not left exposed or dangling to prevent any accidental injury.

Never unplug the refrigerator by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle.

Do not use an extension cord with this appliance. If the power cord is too short, have a qualified electrician or service technician install an outlet near the appliance. Use of an extension cord can negatively affect the performance of the unit.

Know Your Product:



- 1 .Evaporator 2.Ice tray 3. Shelf
5. Thermostat 6.Door sealing stripe 7. Bottle guard

Note: Figure is for illustration purpose only. Actual figure may vary. Please refer to the actual product.

Installation Method:

1. Place the refrigerator on a plain and even surface.
2. Avoid placing upside down or horizontal. The angle should be not less than 45° between the cabinet and the ground when the inclination is necessary.
3. In order to maintain proper cooling and avoid higher energy consumption, please ensure to keep the fridge by maintaining a gap of 5cm from the wall and also ensure to have a space of 30cm from the top.
4. Don't keep the refrigerator in a humid environment.
5. Don't place the refrigerator near heat sources (stove, warmer etc.) or expose the device to direct sunlight.

Operating Instruction:


HOW TO USE THE REFRIGERATOR:

Before you put the refrigerator for first time use please carry out the following steps;

1. Do not connect the power cord to any wall outlet.
2. Keep the refrigerator door open for 30 minutes , so that if there is any left out foul odour , it will be dispersed out to the ambient.
3. Open the refrigerator door; assemble all the accessory parts to it's respective position.
4. Don't keep any food items or beverages for the first time inside the fridge.

5. Insert the power cord into the wall socket.
6. Set the thermostat to maximum position and switch ON the refrigerator.
7. Allow the refrigerator to run for 8 hours; thereafter shut down the refrigerator.
8. Now put the food items and beverages inside the refrigerator.
9. Adjust the thermostat knob based on the season
 - a. For winter- Adjust the thermostat knob to minimum position
 - b. For summer- Adjust the thermostat knob to maximum position

Note: Please refer to the self - explanatory image below; the figure is for illustration purpose only. Actual figure may vary. Please refer to the actual product for thermostat configuration.



Switch ON the refrigerator

Defrost: it is required to periodically inspect the freezer chamber for excess ice deposition. If the ice layer is more than 5 mm, please undertake defrost action immediately.

Switch off the refrigerator, remove all food and beverage items and rotate the thermostat knob in anti-clockwise direction and bring it to off position.

Once the defrost procedure is done, replace food items, and switch ON the fridge

ICE PREPARATION

Pour fresh and clean water into the ice-making tray and maintain the water level as indicated in the ice tray; put the ice tray into the evaporator. Set the thermostat to the maximum position. Ice is made within 2 - 3 hours. Slightly twist round the ice-making tray while taking out the ice.

Attention!

- 1 .While storing the food items, wrap the food item in aluminium foil and store the same in a container with proper lid. This will prevent the smell and keep the food fresh and healthy.
2. There should be proper space between each food items, do not stuff excess food items inside the refrigerator
3. To conserve energy, don't subject the refrigerator door to frequent open and closure.

Maintenance and Care:

1. Periodic maintenance may enhance the life of the refrigerator. Power cord must be pulled out from the wall outlet before carrying out the maintenance activity.
2. Remove the accessory such as bottle guard , steel wire shelve
3. Abrasive powder, washing soda, benzene, petrol, acid, alcohol and hot water etc. shouldn't be used to clean the refrigerator; these may damage the painting and finish of the product and also damage the other plastic parts used in the fridge.

Safety inspection after maintenance


1. Check if the power cord is ok
2. Check if the power plug is ok
3. Check if the wall socket is ok

Trouble Shooting

Phenomenon	Please check it as below
Refrigeration Problem	Check for power failure Check if supply voltage is proper Check if the fuse is OK
Non-satisfactory cooling	Check if the thermostat is in proper position Check if proper space is maintained between the refrigerator and adjoining wall, including free space of 30cm above the the fridge. Check if the fridge door is subjected to frequent open & closure. Check if the fridge is exposed to direct sunlight or any other heat radiating device. Check if the refrigerator is stuffed with excessive food items
Food items in frozen state inside the refrigerator	Check if the thermostat is in maximum position Check if the refrigerator is stuffed with excessive food items
Abnormal noises coming from the refrigerator	Check if the appliance is placed on uneven surface Check if the fridge is in contact with any adjoining goods
Compressor doesn't stop and runs continuously	Check if the refrigerator is stuffed with excess food items Check if the fridge door is subjected to frequent open & closure

Replacing Bulb

Disconnect the power supply before replacing the bulb. Remove the used bulb by turning anti-clockwise. Fix the new bulb by turning clockwise (the bulb should be screw bulb less than 15W).



Technical Specifications:


Main technical data:

Model	LLMB50
Climate Type	ST/T
Electrical Shock Protect Mode	I
Total Capacity (L)	50
Rated Voltage (V)	220-240
Rated Frequency (Hz)	50
Rated Current (A)	0.7
Rated Input Power (W)	70
Energy Consumption (kW.h/24h)	0.7
Refrigerant	R134a
Refrigerant Weight(g)	35
Vesicant	C ₅ H ₁₀ (CP)
Net Weight (kg)	14.5
Noise dB (A)	40
Overall Dimension(mm) [Width Depth Height]	453*455*503

Notice:

All data covered in this catalogue is given as general information. Lifelong reserves the right to change or modify its product line up without prior notice.

Diagram of electrical principle:



Packing list:

Model	LLMB50
Water tray	1
Refrigerator Shelf	1
Instruction manual	1
Ice Tray	1

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year on product , 5 years on compressor

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Terms and Conditions:

1. This warranty is void if:
 - a. The completely filled warranty card is not presented at the time of servicing the product.
 - b. The product is not operated according to the instructions given under the user manual.
 - c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
 - d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
 - e. Product label specifying the model number, serial number and production code has been removed and altered.
 - f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
 - g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
 - h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
2. Repairs or replacements will be carried out by authorized service provider.
3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.
5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not withstanding the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by :
Lifelong Online Retail Private Limited

For queries and complaints:
please contact: customercare@lifelongindia.com
www.lifelongindiaonline.com