


lifelong

HOME

MAKING IT POSSIBLE

# Lifelong SuperCool 85 Air Cooler



Due to continuous product improvement specifications are subject to change. Images shown are for illustrative purposes only and may differ from the actual product.

**1 YEAR**  
WARRANTY

## INTRODUCTION

Welcome to the Lifelong family,


Dear Customer,  
Congratulations on purchasing Lifelong Air Cooler and a warm welcome to the Lifelong family. At Lifelong, we take pride in developing quality products for your home, health and happiness. Through constant innovation in our products, we have been able to develop a wide spectrum of products across Home, Kitchen, Grooming and Wellness categories. We strive to enrich the lives of the modern consumer every day. Keeping that in mind, we have offered all our products at a fair and honest price.

We hope that the Air Cooler serves you and your family's needs without any hassles.

Thanks again for becoming a part of the Lifelong family. Enjoy using the product!

Warm Regards,  
Team Lifelong

## DESCRIPTION OF PARTS



- A. Control Panel.
- B. Side Grill- Right.
- C. Side Grill- Left.
- D. Horizontal Louvers.
- E. Water Tank
- F. Castors

## DESCRIPTION OF PARTS

Power Supply: 230V, 50Hz AC  
Power: 190W

Water Tank Capacity : LLAC265 - 65 L  
LLAC285 - 85 L

Cooling Media: Honeycomb pads.

## OPERATING INSTRUCTIONS

- Choose a suitable location for your cooler.
- The cooler can be operated manually by the control panel located in the front of the cooler.

## FOR ROOM COOLING

- Connect to the power supply and turn the speed knob. The fan will start.
- Turn the speed knob to change the speed from Low to Medium to High.
- To ON turn the cool knob to start cooling. It will take a few minutes to obtain cooling effect.
- When the water in the tank is low turn the cooler OFF and add more water.
- To switch OFF the cooler turn the speed knob to Off position.
- Empty the water tank if the cooler is not being used for some time.

## FILLING WATER

Pour water in the manual water inlet located at the back of the cooler.

## **LOUVERS OPERATION**

- Turn the SWING knob to ON for oscillating the louvre from one side to another. To stop the louvers turn the SWING knob to OFF.
- You can change the air direction (up or down) by manually adjusting the horizontal louver.

## **CLEANING & MAINTENANCE**

Before you clean the cooler, switch the cooler off, remove the plug from the power socket. Use a damp cloth to clean the cooler. DO NOT use water, detergents, petrol, spirits to clean thhe cooler.

- When not in use for a long time store the cooler in a dry, dust free area even during off season.

## **SAFETY PRECAUTIONS**

When using the cooler, basic safety precautions should always be followed:

- Extreme care should be taken when any product is used by, or near children and whenever the cooler is left operating and unattended.
- Before operating the cooler remove it, from its packaging and check whether it is in good condition or not.
- DO NOT let children play with the packing.
- If the supply cord is damaged call your nearest authorized service center immediately.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this cooler as this may void the warranty.
- Check the household voltage to ensure that it matches the rating specifications of the cooler.

**DO NOT cover, or block any of the air outlets.**

**- Always switch off and unplug the cooler before refilling the water tank.**

**- Always unplug the cooler when not in use. To disconnect from the power supply, grip the plug and pull from the power socket.**

**- DO NOT run power cord under carpet, or cover with rugs or runner, arrange the cord away from areas where it may be tripped over.**

**- Avoid the use of an extensionn cable as this may overheat and cause a fire.**

**- DO NOT insert or allow object to enter any ventilation or exhaust opening as this may damage the cooler and could cause an electrical shock or fire.**

**- DO NOT use the cooler in areas where petrol, kerosene or other inflammable material are stored.**

#### **Wheelie bin symbol**

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.



#### **Service**

If you ring Customer Service, please have the Model No. in hand, as we won't be able to help you without it. It's on the rating plate (usually backside of the product)

## Terms and Conditions:

1. This warranty is void if:
  - a. The completely filled warranty card is not presented at the time of servicing the product.
  - b. The product is not operated according to the instructions given under the user manual.
  - c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
  - d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
  - e. Product label specifying the model number, serial number and production code has been removed and altered.
  - f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
  - g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
  - h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
2. Repairs or replacements will be carried out by authorized service provider.
3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.
5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured Market by:  
**Lifelong Online Retail Private Limited**  
Made in India  
For queries and complaints:  
please contact: [customer@lifelongindia.com](mailto:customer@lifelongindia.com)  
[www.lifelongindiaonline.com](http://www.lifelongindiaonline.com)

## Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

### Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: \_\_\_\_\_

Model: \_\_\_\_\_

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: [customercare@lifelongindia.com](mailto:customercare@lifelongindia.com)

### Customer Details

Name: \_\_\_\_\_

Address: \_\_\_\_\_

Home Number: \_\_\_\_\_

Office Number: \_\_\_\_\_

E-mail Address: \_\_\_\_\_

### Product Details

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Invoice Number: \_\_\_\_\_

Online Site: \_\_\_\_\_

Please log onto to [www.lifelongindiaonline.com](http://www.lifelongindiaonline.com) and complete the online warranty form with your personal and product details within 14 days.