

MAKING IT POSSIBLI

ELECTRIC HOT WATER BAG

Instruction Manual



CAUTION:

1. Always keep the indicator front upward when charging. After charging is completed, first cut off the power and then unplug the water heater bag

2. Never use sharp objects to pierce the bag and never use force on the bag. It stops the use and damages the bag further.

3. Always keep the bag on a dry surface only. Use a dry cloth to clean it. Do not dip in water or any other

such substance. They could lead to damage of the bag.

4. Children should be allowed to use the bag only in the presence of an adult

5. Never use the hot water bag while it is being charged

6. Cut off the power immediately if the indicator is not off after charging for 15 minutes

7. The heating liquid has been filled in the bag beforehand. It can only be replaced after getting permission in advance.

OPERATION INSTRUCTION;

1. Place the electric hot water bag on a flat table. Open the bag cover and move the cover plate of the charging point

2. First plug the power cable into the bag and then connect to the wall power socket. The indicator light will turn on and the warmer bag starts charging.

During the charging, normally the bag swells a little. Shake the bag to spread the heating energy evenly.
After the warmer bag has charged for 8-14 minutes, the indicator will turn off and the charging has been completed.

5. First unplug the wall power socket and then disconnect the power cable from the bag to use.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from them date of purchase.

Name of the product:

Model:

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification. Customer Care: customercare@lifelongindia.com

Customer Details

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Terms and Conditions:

1. This warranty is void if:

- a. The completely filled warranty card is not presented at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- C. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
- e. Product label specifying the model number, serial number and production code has been removed and altered.
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
- 2. Repairs or replacements will be carried out by authorized service provider.
- 3. During the limited warranty period, Lifelong or its authorized service provider will repair willhout charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
- All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as will as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warrantied, conditions or other terms implied by statute or common law (including arry warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the lass.

- 6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
- 7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punifive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
- No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by : Lifelong Online Retail Private Limited Made in China For queries and complaints: please contact: customercare@lifelongindia.com

www.lifelongindiaonline.com