

Manufactured for & Marketed by:

Lifelong Online Retail Private Limited

For queries and complaints: please contact: customercare@lifelongindia.com www.lifelongindiaonline.com



Screen



Bone

Massage



Premium Bag

Included



Speed

Settings



6Hr Usage





Available in 2 Colors

1 YEAR WARRANTY

INTRODUCTION:

Dear Customer,

Congratulations! We welcome you to the Lifelong family, as you welcome our Lifelong Massager gun to be a part of your home.

At Lifelong, our products are carefully built for the needs of India, which is why we have crafted a diverse range of innovative products, across a spectrum of categories -Home, Kitchen, Grooming, Fitness, Lifestyle and Smart Home, to better help you. We then deliver them at the best prices, enriching your everyday living.

We are sure you can't wait to start using your new Lifelong Massager Gun.

We know we can't!

Looking forward to building our bond for life, cheers!

Thank you,

TABLE OF CONTENTS:

- 1. About the product
- 2. Marking on product
- 3. How to use
- 4. Maintenance & Care
- 5. Dos and Don'ts
- 6. Technical data/table for specifications

1

ABOUT THE PRODUCT:

Lifelong Gun Massager works its magic across the body with its 6 different heads and it's specially built for relaxation, built for India.

Trusted by loyal users for over five years, we offer you great value for money. With more than 100 innovative products available across categories, it's no wonder millions of shoppers choose Lifelong!

SPECIFICATIONS:



- Turn on the power switch at the bottom of the massage gun.
- Press + and buttons to adjust speed intensity level.
- When the battery power is less than 20%, the LED band line at the bottom of the massage gun will shine RED; when the battery power is less than 10% the LED touchscreen will show EI, indicating that it needs to be charged.
- When the battery is full, the LED band will turn Green.

HOW TO USE:

- Before turning on the Muscle Massage Gun, select the appropriate detachable head for your needs and push it into the massager.
- Power the device on by moving the switch on the bottom of the battery to the ON position. Turn OFF the device by moving the power switch to the OFF position.
- Before turning on the Muscle Massage Gun, select the appropriate detachable head for your needs and push it into the massager.

3

4

- Power the device on by moving the switch on the bottom of the battery to the ON position. Turn OFF the device by moving the power switch to the OFF position.
- Press + and buttons on the LED touch screen to adjust speed.
- The Muscle Massage Gun has up to 20 speed intensity levels
- Massage the desired body part at the desired speed applying pressure as needed.
- To remove and replace detachable heads, simply pull it out gently.

MAINTENANCE AND CARE:

- For maintenance, use a slightly damp towel to clean device and dry with a soft cloth.
- Do not use the product for over 30 minutes continuously, it may activate the over-heat protection device and stops the operation automatically. Please wait at least 30 minutes to let it cool down before re-using.

5

DO's & DONT's

- Do not immerse in water. Keep away from liquids or heat sources. Keep ventilation ports free from dust and debris.
- Do not remove screws or attempt to disassemble.
- Do not operate continuously for more than one hour. Allow device to rest for 30 minutes before re-using.
- Unplug the charger from device after charging or prior to use. Do not over charge device.

ATTACHMENTS:



ROUNDHEAD

Suitable for massaging large muscle groups such as abdomen, glutes and legs. Great for muscle relaxation before and after exercise

6



FLATHEAD

Suitable for large muscle groups such as inside and outside muscles of the abdomen, chest and legs



BONE MASSAGE HEAD

Specially for joint muscle



U-SHAPE HEAD

Suitable for shoulders, neck and bilateral muscles - do not use directly on the cervical spine or spine.



SPADE HEAD

Suitable for relaxation and shaping of various tissue parts, cellulite and fat storage using percussion massage therapy.



CONICAL HEAD

Suitable for applying direct pressure on joints, deep tissue, trigger points and release muscles knots.

TECHNICAL SPECIFICATIONS:

FUNCTIONS	UP TO 20 INTENSITY LEVELS
CHARGE TIME	1 -2 HOURS
ROTATE SPEED	1200 -1300 RPM
VOLTAGE	100 - 240V

Consumer Warranty Card

Dear Customer.

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

date of purchase. Name of the prod	mer products are covered against manufacturing defects from them uct:
Please note: Purch	ase receipt is necessary for warranty verification. Istomercare@lifelongindia.com
Address: Home Number: Office Number:	ls
Serial No.: ——— Purchase Date:	

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Terms and Conditions:

1.This warranty is void if:

a. The completely filled warranty card is not presented

- at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- C. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation. repairs, alterations or modifications by unauthorized

service organizations or persons.

- e. Product label specifying the model number, serial number and production code has been removed and altered
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product
- g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used

for commercial/industrial purposes or which have been rented/leased or have been otherwise subject

to non-household/non-domestic use.

- 2. Repairs or replacements will be carried out by authorized service provider.
- 3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge

the defective unit inclusive of labor and parts and

- 5. Lifelong obligations are limited to the repair and replacement of the defective product, Except as set forth above, there are no other express or implied warranty and all warrantied, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the lass.
- 6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
- 7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special

incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages

the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.

8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should