

Lifelong Online Retail Pvt Ltd
5th Floor, Unit No. 508, DLF
South Court, Saket District
Center, Saket, New Delhi -110017

+91-9711558877
customer@lifelongindia.com
www.lifelongindiaonline.com

LifelongOnlineIn f
Lifelong_Online t
Lifelong.Online i

Lifelong
MAKING IT POSSIBLE

FOOT SPA AND MASSAGER



Customized
massage



Water heating
technology



6 automatic
rollers



Portable

PRODUCT PARTS :



PRODUCT FEATURES:

Automatic heating

Please add warm or cold water below 30 degrees.

When the foot spa machine has been switched on, the heating will start automatically.

Temperature control

With the option of temperature control, you can select the heating temperature of your preference. The default temperature is 35 degrees. It increases by 1 degree. The maximum heating temperature is 48 degrees.

Adjustable time

Enjoy a relaxing massage in the comfort of your home for as long as you want. The appropriate time for a foot spa is generally 20 minutes.

Foot massage

The foot spa massager has automatic foot rollers. These rollers massage the feet thus giving a more relaxed foot spa experience

NOTE:

The appliance has a heating surface and must be used by people who are not sensitive to heat. If water overflows from the massager, it cannot be used.

METHOD OF USE:

- 1.Place the foot spa massager in front of a chair. Add water to the appropriate water level.
- 2.Press the power button to switch it on. Press the button again to turn of the massager.
- 3.After switching on the massager, put your feet into the foot spa and adjust the settings as per your preference.
- 4.Set the timer. The appropriate time for foot spa is generally 20-30 minutes which can be adjusted accordingly.
- 5.Before switching the massager off, turn off the heating button. Press the power button to switch of the massager.

MAINTENANCE AND PRECAUTIONS:

1. Add water first and then switch on the massager. It is strictly prohibited to use without water.
2. It is strictly prohibited to stand in the tub. It could lead to breakage of the tub's body.
- 3.When the massager is not in use, please empty the tub and place it in a shady area
- 4.Before leaving the factory, every machine will be opened and water released for inspection (This is done to test whether all functions are running normally). There could be some stains of water droplets which is normal. The products are unused.
- 5.Drink 1-2 cups of plain water before a pedicure in order to facilitate circulation and detoxification in the body. During the foot spa if you feel dizzy, pause for a while. When you feel better, you can start the foot spa. Sweating is a normal phenomenon but if you sweat excessively then stop.
- 6.During a foot spa, blood vessels of foot dilate and blood volume increases, resulting in decreased gastrointestinal and visceral blood. This affects the gastrointestinal digestive function. Avoid foot spas 30 minutes before and after meals

7. People who are insensitive to heat must be accompanied by someone. Patients with pacemakers and women during menstruation and pregnancy must follow the doctor's advice
8. After your foot pedicure/spa has been completed, drain the water inside the machine, wash again once with fresh water and let it dry in a cool place. If there is water stored in the machine for a long time, it may cause moisture damage to the internal parts.
9. If the product is to be cleaned, do not use alcohol, gasoline and other solvents. Wash with soap or detergent and rinse properly with fresh water,
10. If the power cord is damaged, please contact the customer care.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from the date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note:

Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log on to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Terms and Conditions:

1. This warranty is void if:

- a. The completely filled warranty card is not presented at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
- e. Product label specifying the model number, serial number and production code has been removed and altered.
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.

2. Repairs or replacements will be carried out by authorized service provider.

3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.

4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.

6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.

7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply notwithstanding the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.

8. No carrier, dealer or employee is there of authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.