


وسمعلنا

GLIDE CEILING FAN



1200 mm
Blades




High Speed
Fan (380RPM)



Double ball
Bearing



Full Copper
Motor



Dear Customer

Congratulations on your purchase of a Lifelong ceiling fan! Your new fan will be a beautiful addition to your home, and will keep you comfortable throughout the year. We're certain that your Lifelong fan will provide you with many years of comfort, energy savings and satisfaction. To ensure your personal safety and to maximize the performance of your fan, please read this manual thoroughly.

1. SAFETY RULES:

- i) Before you begin installing the fan, shut the power off at the circuit breaker or the fuse box.
- ii) Be cautious! Read all instructions and safety information before installing your new fan. Review accompanying assembly diagrams.
- iii) Make sure that all electrical connections comply with local codes, ordinances, or National Electrical Codes. Hire a qualified electrician or consult a do-it-yourself wiring handbook if you are unfamiliar with installing electrical wiring.
- iv) Make sure the installation site you choose allows the fan blades to rotate without any obstructions. Allow a minimum clearance of 7 feet from the floor to the lowest edge of the blades and 18 inches from the tip of the blade to the wall.
- v) **Caution:** To reduce the risk of personal injury use only the screws provided with the outlet box.
- vi) If you are mounting the fan to a joist, make sure it is able to support the moving weight of the fan

2. ASSEMBLY & INSTALLATION:

- i) Place the motor on the thermo buffer.
- ii) Pass the connection wires through the slit hole at the bottom end of down rod (3) and remove them from the top end of down rod.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 2 Years

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____


Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log onto to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.



iii) Insert the bottom end of down rod (3) (with slits) on spindle (6) and insert bolt. (7) Place the spring washer (8) and fully tighten nut. (9) Insert the split pin (10) in the small hole on the bolt end and open the ends, so that it does not fall off. The assembly of bolt (7), spring washer (8), nut (9), split pin (10) is separately packed with the hanger assembly (11).

iv) Connect the wires to the terminal block. Do not insert anything into the fan blades while the fan is operating.

v) Insert the condenser cover (4) from top end of down rod and place it in position. Ensure minimum 3 to 4mm gap between the condenser cover (4) and motor body and tighten the screw (4a) (in case of screw type) which is provided on the condenser cover.

vi) Insert the canopy (5) from top end of the down rod (3).

viii) Fix the blade (1) with the screws (2) already provided on the motor body.

ix) Remove the split pin (15), nut (14), spring washer (13) bolt (12), at the bottom end of the hanger assembly (11).

x) Place hanger assembly (11) in ceilings hook in such a way that the rubber reel (16) rests on the ceiling hook.

xi) Insert the top end of the down rod (3) between the steel clamps of hanger assembly (11). Match the holes with holes in down rod. Insert bolt (12). Place spring washer (13), and fully tighten nut (14). Insert the split pin (15) in the small hole on bolt end and open the ends, so that it does not fall off.

xii) Lift the canopy (5) to cover hanger assembly and tighten the screw (5a) (in case of screw type) provided on canopy. xiii) Connect the regulator in series with the fan.

Terms and Conditions:

1. This warranty is void if:

- The completely filled warranty card is not presented at the time of servicing the product.
 - The product is not operated according to the instructions given under the user manual.
 - Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
 - Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
 - Product label specifying the model number, serial number and production code has been removed and altered.
 - Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
 - Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
 - Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
- Repairs or replacements will be carried out by authorized service provider.
 - During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
 - All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.

- Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
- Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
- However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
- No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Manufactured for & Marketed by :
Lifelong Online Retail Private Limited
Made in India

For queries and complaints:
 please contact: customercare@lifelongindia.com
www.lifelongindiaonline.com