لنابطمي **AIR COOLER User Manual**

Built for Home. Built for India.

Manufactured for & Marketed by :

Lifelong Online Retail Private Limited

For queries and complaints: please contact: customercare@lifelongonline.com www.lifelongindiaonline.com

INTRODUCTION:

Dear Customer,


Congratulations! We welcome you to the Lifelong family, as you welcome the Lifelong Air Cooler to be a part of your home.

We started Lifelong Online with a simple dream of being a part of every Indian household, which is why we have produced a varied assortment of innovative products across a spectrum of categories - Home, Kitchen, Grooming, Fitness, Lifestyle, and Smart Home - to better assist you.

We hope you enjoy using our Air Cooler as much as we enjoyed designing it for you.

Delivering promises that last lifelong.

Thank you for choosing us, Lifelong Built For India



LLAC912


TABLE OF CONTENTS:

- 1. About the product
- 2. Marking of Product
- 3. Product Specifications
- 4. Quick Start Guide
- 5. Operating Instructions
- 6. Device Cleaning and Maintenance
- 7. Dos & Don'ts
- 8. Troubleshoot Chart
- 9. Terms and Conditions
- 10. Warranty

ABOUT THE PRODUCT:

The lifelong Air cooler is perfect for small to medium-sized rooms. Its sleek and compact design also makes it perfect for effective personal cooling while occupying very little space.

MARKING OF PRODUCT:



- 1. Ice Chamber
- 2. Speed Knob
- 3. Swing Knob
- 4. Control Panel
- 5. Blower
- 6. Water Tank
- 7. Water Indicator Level
- 8. Drain Plug

3

PRODUCT SPECIFICATIONS:

SKU ID	LLAC912
Tank Capacity (Ltr)	12
Power Supply	220-240 V, 50 Hz
Power Consumption (W)	80
Air Delivery	1416 m³/hr
RPM	2000
Speed	3
Cooling Media	Honey Comb
Product Dimensions(mm)	250 mm X 250 mm X 600 mm
NW (kg)	5.1 kg
GW (kg)	6.1 kg

QUICK START GUIDE:

Read all instructions carefully before setting up and operating the unit, and please keep this instruction manual for future reference. This manual is designed to provide you with important information needed to setup, operate, maintain, and troubleshoot your cooler. Failure to follow these instructions may damage and/or impair its operation and void the warranty.

1. Fill with water and plug into standard power outlet.

Note: Please make sure that the power outlet is set to correct settings as per product specifications.

2. Place near open door or window.

Note: Evaporative Air Coolers work on evaporative cooling mechanism which requires cross ventilation.

- 3. Keep a minimum distance of 0.5M from the wall.
- 4. Turn ON and enjoy the cooling breeze.

Note: Start with LOW speed and gradually increase to higher speed for optimum cooling performance.

5. Keep the room ventilated for maximum efficiency.


OPERATING INSTRUCTIONS:

- · Choose a suitable location for your cooler.
- The cooler can be operated manually by the control panel located in the front of the cooler.

FOR ROOM COOLING:

- Connect to the power supply and turn the speed knob. The fan will start.
- Turn the speed knob to change the speed from Low to Medium to High.
- To ON turn the cool knob to start cooling. It will take a few minutes to obtain cooling effect.
- When the water in the tank is low turn the cooler OFF and add more water.
- To switch OFF the cooler turn the speed knob to Off position. Empty the water tank if the cooler is not being used for some time.

Note: Evaporative air coolers are built to maximize energy efficiency and keep costs low. This no-compressor system cools naturally, efficiently and inexpensively. The recommended relative humidity is 60% or less which allow noticeable temperature to decrease in the air.



TO FILL THE WATER:

Pour water in the manual water inlet located at the back of the cooler.

OPERATION OF LOUVRES:

Turn the SWING knob to ON for oscillating the louvre from one side to another. To stop the louvers, turn the SWING knob to OFF. - You can change the air direction (up or down) by manually adjusting the horizontal louver.

DEVICE CLEANING AND MAINTENANCE:

- Before you clean the cooler, switch the cooler off, remove the plug from the power socket. Use a damp cloth to clean the cooler.
- DO NOT use water, detergents, petrol, spirits to clean the cooler.
- When not in use for a long time store the cooler in a dry, dust free area even during off season.

DOS & DON'TS:

- To avoid electric shock, fire or injury, please read the user manual carefully before using the appliance and keep it for future reference.
- This appliance is for household use only. Please use suitable power source (Please refer to SPECIFICATION).
- Never immerse the appliance in water or other liquids.
- Do not use the appliance under direct sunshine.
- Please turn off the appliance when not in use otherwise it may result in danger. Please turn off the appliance and unplug the socket when unattended otherwise it may result in danger.
- Keep the appliance away from children.
- The appliance is not intended to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- With any indication of malfunction, please stop using the appliance immediately to avoid hazards. call the authorized customer care number for repair. Do not attempt to repair or change any parts by yourself.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid hazard.
- Please turn off and unplug the appliance before water filling, cleaning or maintenance.
- Clean the surface of the appliance with dry cloth. Do not use corrosive detergent or solvent to clean. Do not swash the appliance with water.
- Please turn off and unplug the appliance when not in use. Make sure the power is off before pulling out the plug and do not pull the cord.

TROUBLESHOOT CHART:

No discharge of air	Cord is not plugged in.	Make sure power cord is plugged in and the supply switch is on.
	Power is not on.	Turn the unit ON by changing the mechanical knob position of the control panel.
	Motor Faulty.	Contact service centre.
Not cooling/ Unit is making noise	Pump or not turned on.	On control Panel. Turn COOL FUNCTION TO "ON"
	Low or not water in tank, when COOL is selected.	Refill water tank.
	Damaged pump.	Contact service center.
Odor omission	When the cooler is new.	When the unit is used for the first time, the honeycomb cooling media will have an odor, which will dissipate within a week of initial use. This is normal.
	If the cooler has been used. There may be an algae issue.	Water is stale clean the tank and fill with fresh water.
		Clean the honeycomb media.
		If problem persists contact the service center.

9

Terms and Conditions:

- 1. This warranty is void if:
- a. The completely filled warranty card is not presented at the time of servicing the product.
- b. The product is not operated according to the instructions given under the user manual.
- c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
- d. Product has been damaged due to installation. epairs. alterations or modifications by unauthorized service organizations or persons.
- e. Product label specifying the model number, serial number and production code has been removed and altered.
- f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
- a. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
- h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
- 2. Repairs or replacements will be carried out by authorized service provider.
- 3. During the limited warranty period. Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
- 4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as will as any other expenses and incidentals will be borne by the consumer.

- Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warrantied, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the lass.
- 6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
- 7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
- 8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Online Site:

Warranty Service	
All Lifelong consumer products are covered against manufacturing defects fr	roi
them date of purchase.	
Name of the product:	
Model:	
Warranty coverage: 1 year	
Please note: Purchase receipt is necessary for warranty verification. Customer Care: customercare@lifelongonline.com	
Customer Details Name:	
Address:	
Home Number:	
Office Number:	
E-mail Address:	
Product Details Model No.:-	
Serial No.:	
Purchase Date:	

Please log on to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.