


Lifelong

MIXER GRINDER

User Manual



Manufactured for & Marketed by :
Lifelong Online Retail Private Limited

For queries and complaints:
please contact: customercare@lifelongonline.com
www.lifelongindiaonline.com

Built for Taste. Built for India.

INTRODUCTION:

Dear Customer,

Congratulations!

We welcome you to the Lifelong family, as you welcome the Lifelong Mixer Grinder to be a part of your home. We started Lifelong Online with a simple dream of being a part of every Indian household, which is why we have produced a varied assortment of innovative products across a spectrum of categories -Home, Kitchen, Grooming, Fitness, Lifestyle, and Smart Home -to better assist you.

We hope you enjoy using our Mixer Grinder as much as we enjoyed designing it for you.

Delivering promises that last lifelong.

Thank you for choosing us,
Lifelong
Built For India



LLMG75

TABLE OF CONTENTS:

1. About the product
2. Dos and Don'ts
3. Product Usage Instructions
4. Overload protection
5. Device Cleaning
6. Troubleshooting
7. Specifications
8. Terms & Conditions
9. Warranty Card

ABOUT THE PRODUCT:

The 750 W Mixer grinder is an essential addition to your kitchen that gives you great value for money. This durable multi-purpose mixer grinder, equipped with four jars can be your preferred kitchen companion. Its multi-purpose blades are perfect to grind raw masalas for delicious pastes as well as curries.

DOS AND DON'TS:

- Keep the Lifelong Mixer Grinder away from heat and sunlight
- Clean the jars carefully before use
- Do not place the machine on a wet surface
- Never try to touch the moving parts or blades of the mixer grinder while operation
- Never insert your hand or spatula or spoon, when in use
- Never operate the mixer grinder without the jar lid
- The jars can be cleaned by using regular dishwashing soap.
- After thoroughly rinsing with soap, clean the jars with a dry cloth.
- Never store the jars with closed lids.
- Do not use any detergent soap solutions on the main body.
- Clean the body with a dry cloth before storing for next use.
- Never immerse the motor in the water for cleaning
- Never pull the cord to take out the plug from the socket
- Always switch off the power supply button before cleaning, emptying or when not in use.

PRODUCT USAGE INSTRUCTIONS:

FRUIT FILTER JUICER JAR

STEP 1: Insert the fruit filter into the blender jar and rotate it slightly so that it settles down and the grooves get locked with the slugs on the blender jar wall.

STEP 2: Place the lid on the jar and rotate it anti-clockwise to lock.

STEP 3: Place the assembly onto the drive shaft of the juicer mixer grinder and rotate clockwise to lock it into position.

STEP 4: Cut small pieces of fruits to be juiced.

STEP 5: Remove the cap on the lid by rotating anticlockwise. Put the cut pieces into the filter and switch on the juicer mixer grinder.

STEP 6: You can continue adding more fruit pieces from the centre opening in the lid as they are juiced.

STEP 7: The juice is sieved out through the filter and the pulp/seeds get accumulated inside the filter and pour out the contents from the jar by tilting.

Liquidizing and blending jar

STEP 1: The Liquidizing and blending jar is used for preparation of shakes, juices etc.

STEP 2: Before starting the mixer grinder for the first time or after a long period of time, rotate the motor shaft with hand to ensure that it turns freely and smoothly.

STEP 3: Place all the ingredients in the jar and close the lid properly

STEP 4: Now switch on the grinder for operation

Note: Do not use this jar for wet grinding

Chutney making jar

STEP 1: The chutney jar is mainly used for making chutney.

STEP 2: Use small pieces of ingredients for grinding.

STEP 3: Put the ingredients in the chutney jar for grinding. Hold the lid tightly so that it doesn't pop up.

STEP 4: The ingredients should not be too large. Break ingredients into smaller pieces.

Note: The lid should be properly pressed.

- If you must reset the OLP again and again, try reducing the quantity of ingredients in the Jar

CLEANING INSTRUCTIONS:

- Before use pour warm water in the jar, run for a few seconds and throw away the water.
- The cleaning of the mixer grinder and jars are very necessary for maintaining smooth operation of the mixer grinder and proper hygiene.
- After you have used the mixer grinder, use warm water to remove the smell of the material from the jars and then rinse under running water.
- In order to clean the blades thoroughly, remove the blades by using the spatula to loosen the screw by twisting the dome nut on the blade clockwise, while holding the coupler from under the jar.

TROUBLESHOOTING GUIDE:

S.No	Problem	Cause	Action	Remark
1	The Mixer grinder does not start.	No power supply tripped due to overload.	Ensure that the power supply is off. Remove excess load & reset the OLP located at the bottom of the mixer grinder.	If it still does not work, please contact Lifelong customer care center.
2	The result/performance is not satisfactory.	Overloading Sizes of the ingredients do not fit the jar.	Fill the chutney jar up to the level of blades & the other 2 jars up to 2/3 of capacity level indicated. Cut/Brake down the ingredients to be ground into appropriate size.	
3	Mixer grinder generates abnormal noise.	Jar is not locked properly Blade assembly loose Coupler loose.	Lock the jar properly Tighten nut of blade assembly properly Tighten coupler.	

SPECIFICATIONS

S. No.	Specification	LLMG75
1	Wattage	750 W
2	Warranty	1 Year
3	Power Supply	220-240 V, 50 Hz
4	Speed Control Switch	Yes
5	Overload Protection (OLP)	Yes
6	No. of Jars	4
7	Body Material	ABS
8	Jar Material	3 Stainless Steel, 1 Plastic Jar
9	Blade Material	Stainless Steel

Terms and Conditions:

1. This warranty is void if:
 - a. The completely filled warranty card is not presented at the time of servicing the product.
 - b. The product is not operated according to the instructions given under the user manual.
 - c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
 - d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
 - e. Product label specifying the model number, serial number and production code has been removed and altered.
 - f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
 - g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
 - h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
2. Repairs or replacements will be carried out by authorized service provider.
3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not withstanding the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not rely on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from the date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongonline.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log on to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.

Wet/Dry grinding jar

STEP 1: The wet /dry grinding jar is used for grinding items like Idli and Dosa batter, coconut chutney, groundnut, red chilli powder, sugar, palak etc.

STEP 2: Make sure that the dry grinding jar is clean and dry before use.

STEP 3: Use small pieces of ingredients for grinding.

STEP 4: Fill the jar with ingredients up to the marked capacity.

STEP 5: Put the flat lid on top of the Jar. Grind at low speed for 15-30 seconds and then move to higher speed

Note: Always move gradually from lower speeds to the higher speed. During the grinding process, as the jar might pop up due to friction.

Do not panic. This happens gradually

SPECIAL INSTRUCTIONS FOR USING FRUIT FILTER:

1. Place the fruit filter inside the blender jar such that its flour slots fit into the four ribs inside the blending jar.
2. Press it down so that it is fixed properly.
3. Fruits should be cut into small pieces before putting inside the fruit filter for extracting the juice.
4. Close the jar Lid.
5. Initially use low speed and then speed can be increased.
6. After juicer is done, pour the contents into a glass.

OVERLOAD PROTECTION:

- The overload protector (OLP) is designed to protect the motor from burning.
- In case of an overload, the blade of the jar stops rotating, and the motor gets jammed or starts heating up.
- If such a situation occurs the mixer grinder will automatically trip off and hence protect the motor.
- Let the motor cool down for a couple of minutes. The red button of the overload protector switch located at the bottom of the mixer grinder must be pressed for re-operation.