

Manufactured for & Marketed by :
Lifelong Online Retail Private Limited

For queries and complaints:
please contact: customercare@lifelongindia.com
www.lifelongindiaonline.com

lifelong

FOLDABLE FOOT SPA MASSAGER

User Manual



Built for Relaxation. Built for India.

INTRODUCTION:

Dear Customer,

Congratulations! We welcome you to the Lifelong family, as you welcome the Lifelong Electrical Foldable Foot Spa Massager to be a part of your home.


At Lifelong, our products are carefully built for the needs of India, which is why we have crafted a diverse range of innovative products, across a spectrum of categories - Home, Kitchen, Grooming, Fitness, Lifestyle and Smart Home, to better help you. We then deliver them at the best prices, enriching your everyday living.

We are sure you can't wait to start using your new Lifelong Electrical Foldable Foot Spa Massager.

We know we can't!

Looking forward to building our bond for life, cheers!

Thank you, Team Lifelong



LLM810

TABLE OF CONTENTS:

1. About the product
2. Marking of Product
3. Safety Precautions
4. Operating Instructions
5. Device Cleaning
6. Terms & Conditions
7. Warranty Card

ABOUT THE PRODUCT:

Lifelong Electrical Foldable Foot Spa Massager is the ideal way to unwind & relax at the end of a busy tiring day on your feet, at work or home. Easy to use anywhere in the house, it's the perfect answer to revive & energise you.

MARKING OF PRODUCT:



SAFETY PRECAUTIONS:

To avoid the risk of fatalities from electric shock:

- Make certain that the power cord does not become wet or moist during operation.

Place it such that it cannot be crushed or damaged.

- Do not use the Foot Spa Massager machine without the water.
- Keep the power cable away from hot surfaces.
- Do not carry out any repairs on the appliance. All repairs must be carried out by the manufacturer or its service agent or a similarly qualified person.
- Unplug the appliance before filling it with water or cleaning it.
- Arrange for defective power plugs and/or cables to be replaced as soon as possible by a qualified technician or by our Customer Service Department to avoid the risk of injury.

To avoid damaging the device:

- Do not stand in or on the foot spa. Use it only while seated.
- Do not use the Foot Spa Massager machine without the water.
- Never operate the foot spa for longer than 60 minutes. The appliance is not meant to be used continuously for extended periods. Allow the appliance to cool sufficiently before using it again.
- Do not use any foam-producing bath additives. The appropriate bath additives for bubble baths are available from specialized dealers.
- Do not fall asleep while using the foot spa.
- Never operate the appliance while you sleep.

OPERATING INSTRUCTIONS:**Setting up****1. Unfolding the Foot Bath.**

Hold the left and right sides of the bottom with both feet, grasp both sides of the edges of the bucket with both hands, and pull up until it has completely unfolded. After fixing the left and right supporting frames in the bucket, it can be used.

2. Add the water to the tub before plug in.**3. Plug in the Foot Massager Spa and turn the massager on by pressing the power button.****4. Let the water heat.****5. The massage rollers are manual.****6. You can set the timer and the temperature according to your comfort level.****Using the foot spa****1. Now place your feet in the water container.**

2. During the water bath you can massage the soles of your feet by moving your feet forward and backward on the rollers.

After the foot bath

1. Turn the appliance off by pressing POWER and remove the plug from the electrical socket.

2. Carefully empty the water out through the water drainage pipe which is installed on the back.

3. Then rest for a while.

4. Folding the Foot Bath.

Break off the upper part of the supporting frames on both sides of the bucket and lay the bottom flat. Press both hands on the left and right sides of the upper edge of the bath and press down at the same time to fold the foot bath.

DEVICE CLEANING:**Warning! Risk of injury!**

- Unplug the appliance, before cleaning it.
- Let the appliance cool sufficiently before cleaning it.
- Never immerse the appliance in water or other liquids to clean it.

Warning!

- Do not use any aggressive cleaning liquids or solvents. They could damage the surface.
- Do not use it without water.

Terms and Conditions:

1. This warranty is void if:
 - a. The completely filled warranty card is not presented at the time of servicing the product.
 - b. The product is not operated according to the instructions given under the user manual.
 - c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
 - d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
 - e. Product label specifying the model number, serial number and production code has been removed and altered.
 - f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
 - g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
 - h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
2. Repairs or replacements will be carried out by authorized service provider.
3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised servicer.
4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as well as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from them date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongindia.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log on to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.