

Manufactured & Marketed by :
Lifelong Online Retail Private Limited

For queries and complaints:
please contact: customercare@lifelongonline.com
www.lifelongindiaonline.com

lifelong

FOOT AND CALF MASSAGER

User Manual



Built for Relaxation. Built for India.

INTRODUCTION:

Dear Customer,

Congratulations!

Welcome to the world of Lifelong! Just like you're bringing our Lifelong Foot and Calf Massager into your life, we've made it with care to fit your daily needs. Here at Lifelong, we meticulously design our products to cater to your everyday requirements. This is the reason behind our diverse product lineup aimed at enhancing your comfort. We subsequently offer these products at highly competitive prices with the aim of providing you and your family a soothing experience throughout the day. We know you're excited to use your new Lifelong Foot and Calf Massager.


We're excited too, and we look forward to being friends for a long time.

Cheers to the exciting journey ahead!

Thank you for choosing us,

Team Lifelong!

Built For India



LLM918


TABLE OF CONTENTS:

1. About the Lifelong Foot and Calf Massager
2. Using the Lifelong Foot and Calf Massager
3. Maintaining the Lifelong Foot and Calf
4. Safety Precautions
5. Troubleshooting
6. Terms & Conditions
7. Warranty Card

ABOUT THE LIFELONG FOOT AND CALF MASSAGER:

The Lifelong Foot and Calf Massager with air compression is a revolutionary device designed to provide relaxation, relief, and rejuvenation for your feet and calf muscles. Combining advanced technology with therapeutic benefits, this massager offers a convenient and effective way to address the stresses and strains that accumulate in these areas due to daily activities and prolonged periods of standing or walking.

USING THE LIFELONG FOOT AND CALF MASSAGER:



1. Press the power button (Power button):

The switch light will turn on, and the mode and heating buttons will also activate. Pressing the power switch key again will halt all functions, and the switch light will change from constant to flashing

2. Intensity key (Air button):

Adjust the air pressure intensity, divided into three levels: low, medium, and high. The indicator light flashes slowly at low gear, constantly at medium gear, and rapidly at high gear.

3. Mode button (Mode button):

The mode has three settings: Soothe, Relax, and Refresh. You can select the one you prefer.

4. Roller button (Roller button):

Adjust the roller speed among three options: low, medium, and high.

The indicator light flashes slowly at low gear, constantly at medium gear, and rapidly at high gear.

5. Heating button (Heat button):

The heating option is turned on by default. Pressing the heating button for the first time deactivates the heating, and the indicator light turns off.

Press it again to activate instep and calf heating functions, and the indicator light remains on until the button is pressed again.

MAINTAINING THE LIFELONG FOOT AND CALF MASSAGER:

Storing the Massager:

- When the product is not in use, place it in a box and store it in a dry, ventilated, and cool area.
- Avoid twisting the wires.
- Prevent scratching the product's surface by avoiding contact with sharp objects.
- Keep away from direct sunlight and high temperatures.

Cleaning the Massager:

- Before cleaning, unplug the power cord.
- Clean the product's surface using a dry cloth only. Avoid direct water contact.
- Refrain from using corrosive cleaners such as benzene-based or bleach products.
- The fabric pouch can be removed for cleaning.

Maintaining the Massager:

- Keep the product clean and away from moisture.
- Cover the product when not in use to prevent dust accumulation.

SAFETY PRECAUTIONS:

1. Prevent any dust or dirt from entering the gap between the massage head and the casing.
2. Avoid getting the massager wet to prevent short-circuiting. Keep away from water or other liquids.
3. If the main cable or plug is damaged, do not attempt to turn on the massager or repair the plug. Contact your supplier for troubleshooting instructions.
4. After use and before cleaning, disconnect the plug from the power supply to avoid electrical injury.
5. Avoid placing heavy objects on the massager when not in use.
6. Do not use the massager if you are unwell, under the influence of alcohol, pregnant, or have medical conditions.
7. Refrain from using the product for at least an hour before or after eating.
8. Avoid using the massager immediately after a sudden temperature change.
9. Do not use the product in dusty or corrosive conditions.
10. Do not cover the massager with a blanket or pillow during use.
11. Avoid falling asleep while using the product.
12. Do not use the massager if you have contagious skin conditions.
13. Avoid using the product if you have osteoporosis or other bone or muscle conditions.

14. Do not use the product if you have a heart disease or use electrical medical instruments like pacemakers.
15. Avoid using the product if you have a high fever.
16. Do not use the massager if you have injuries or are in the process of recovery.
17. The massager has a heated surface. Individuals sensitive to heat must use this massager cautiously.
18. Do not use the product while wet or in close proximity to water.
19. Do not use the product on children or pets.

TROUBLESHOOTING:

Situation	Possible Reasons	Troubleshooting
Massager not responsive	No power	Check power supply
	Function keys are not responsive	Restart machine using On/Off button or unplug the device
Massager suddenly stops operating	No power	Check power supply
	Massager in-use for more than 15 minutes	Turn off machine to allow cool-down period. Restart machine using On/Off button
	Overheating due to overuse	Turn off machine to allow cool-down period. Restart machine using On/Off button
	Auto-cut off due to excessive force	Relax feet when massager is on
Noise	It is normal for rollers, airbags, motors and materials to make noises when in operation.	

Terms and Conditions:

1. This warranty is void if:
 - a. The completely filled warranty card is not presented at the time of servicing the product.
 - b. The product is not operated according to the instructions given under the user manual.
 - c. Damages are caused by lightning, abnormal voltage, water or other liquid intrusion, fire, flood, accident, negligence or improper handling.
 - d. Product has been damaged due to installation, repairs, alterations or modifications by unauthorized service organizations or persons.
 - e. Product label specifying the model number, serial number and production code has been removed and altered.
 - f. Defects or parts requiring replacement due to ordinary wear and tear, corrosion, rust or stains, scratches, dents on the casing or paintwork of the product.
 - g. Claims damaged and/or missing parts (accessories) after 7 days from the original date of goods received.
 - h. Defects or faults in product which have been used for commercial/industrial purposes or which have been rented/leased or have been otherwise subject to non-household/non-domestic use.
2. Repairs or replacements will be carried out by authorized service provider.
3. During the limited warranty period, Lifelong or its authorized service provider will repair without charge the defective unit inclusive of labor and parts and restore the unit to its optimum working condition. All defective parts used for the warranty repair should be surrendered to Lifelong and/or its authorised service provider.
4. All expenses incurred in collecting the unit (s) or part(s) thereof from authorised service provider as will as any other expenses and incidentals will be borne by the consumer.

5. Lifelong obligations are limited to the repair and replacement of the defective product. Except as set forth above, there are no other express or implied warranty and all warranted, conditions or other terms implied by statute or common law (including any warranty of satisfactory quality, merchantability or fitness for a particular purpose) are excluded to the fullest extent permitted by the law.
6. Lifelong total liability for damages relating to or arising out of the purchase or use of the product regardless of the type or cause of such damage of the form of characterization of the claim asserted (e.g. contract or tort) shall not exceed the original purchase price paid for the product.
7. However in no event shall Lifelong and Lifelong authorized distributors be liable for any punitive, special incidental, indirect or consequential losses or damages whatsoever (including without limitation, damages for the loss of revenue, business, profits, goodwill, or contracts, business interruptions, loss of business information or any other pecuniary loss.) Whether or not Lifelong has been advised of the possibility of such damages. These limitations shall apply not with standing the failure of the essential purpose of any limited warranty. This limited warranty does not affect consumer's statutory rights under the law.
8. No carrier, dealer or employee is thereof authorized to make modifications to this warranty and you should not reply on any such representation. Lifelong reserves the right to amend the terms and conditions if necessary.

Consumer Warranty Card

Dear Customer,

Thank you for choosing a Lifelong consumer product. All Lifelong Consumer products are designed and manufactured to the highest standards to deliver high quality performance, as well as easy installation and use. At Lifelong, we believe in providing not only service, but adding value to your purchase. The warranty has therefore been designed especially for you with your interest at heart.

Warranty Service

All Lifelong consumer products are covered against manufacturing defects from their date of purchase.

Name of the product: _____

Model: _____

Warranty coverage: 1 year

Please note: Purchase receipt is necessary for warranty verification.

Customer Care: customercare@lifelongonline.com

Customer Details

Name: _____

Address: _____

Home Number: _____

Office Number: _____

E-mail Address: _____

Product Details

Model No.: _____

Serial No.: _____

Purchase Date: _____

Invoice Number: _____

Online Site: _____

Please log on to www.lifelongindiaonline.com and complete the online warranty form with your personal and product details within 14 days.